TRISM IV

User Manual



No cardholder shall leave the new accounts desk without a working debit card in their hand. Period.

DemoTeller Systems, Inc. 1212 Royal Parkway Euless, TX 76040 817.494.9300 • www.demoteller.com



Table of Contents

What is TRISM IV?	
TRISM IV Desktop Icons	
Configure	3
General	3
Users	4
Add Users	4
Edit Users	4
Templates	5
Formats	6
General Settings	6
Encode Settings	7
Emboss Settings	8
Mailers	9
Photo Settings	9
Custom Background	
Devices	
Adding a printer or embosser	
Active Directory	
Branches	
Add and remove vaults, devices, and PCs	
Interfaces	17
Interface Settings	
Interface BIN Settings	
MSR	18
Adding MSRs	
Moving an MSR to another computer:	
Inventory	
Vault Inventory	19
Adding vaults	19
Tracking cards	
Device Access	20
Adding/removing cards and changing ribbon/foil	
Card Stock Inventory	
Card Stock ID	22
Card Stock to BIN	
Card Stock to Device	23

Request	24
Order Card	24
Personalizing and Previewing Cards	25
Edit Permissions	27
Re-PIN	28
PIN Mailer	29
Queue	30
Reports	31
End of Day	31
Tips for Balancing End of Day Reports	31
Device Inventory	31
Vault Inventory	32
Spoil Cards	33
Management	36
Historical Card Balancing	38
Data Log	40
Error Log	41
Help	42
About	42
Appendix	43
Card Layouts	43
Permission Descriptions	44

What is TRISM IV?

TRISM IV is the latest card issuance suite developed by DemoTeller Systems, Inc. This unique hardware and software system provides all the tools needed for the creation and distribution of financial cards of any kind.

Initially introduced in the late 1990's, TRISM provides instant and central issuance of Visa® and Mastercard® credit and debit cards to financial institutions worldwide.

TRISM works seamlessly with the PCI-certified and listed Hardware Security Module (HSM) to ensure complete privacy of cardholders' information.

From centrally issued, pre-printed cards to customer created cards available for immediate use, TRISM IV boasts the versatility to meet any institution's most specific demands.

TRISM IV Desktop Icons



TRISM Manager



HSM Manager



Card Designer




Server



Print Controller

Configure

General



- 1. All TRISM IV user passwords will expire after the amount of days specified. New passwords for each user must be created at that time. (Disregard if Windows Active Directory is enabled)
- 2. The PIN pad derivation key is provided by DSI for setup of the HSM. It can be found in HSM Manager in the Key Management tab.
- 3. If an old version of a PIN pad is being used that does not automatically generate an encryption key, a new encryption key will be generated by T4 after the specified amount of days.
- 4. Click **Choose Directory** and select the location where TRISM updates will be saved.
- 5. Check box if using a Citrix virtual server and select the assigned port from the dropdown menu. Ports do not need to be assigned per user if they are assigned for the entire system.

Users


The following user configuration is disabled if Windows Active Directory is enabled.

Add Users

To add a new user, select **Users** from the left-hand Configure menu. Click **Add**, and enter the user information in the provided fields.



When the new user logs in, they must use the default password **1234567**. When **Login** is clicked, a window will open prompting the user to change their password. All passwords must be at least 8 characters long and include at least three of the following: capital letters, lowercase letters, numbers, and special characters (!@#\$%^&*).



Enter the new password in the provided fields and click **OK**. The user will then be redirected to the TRISM IV main menu.

Alternatively, users may be entered using the Active Directory function.


Edit Users

Select a user in the User list and click **Edit**. Make the desired changes and click **Save**.




Templates

A template may be used to automatically assign a user a specific set of permissions. See the Appendix for permission descriptions.



To enable or disable permissions, select **Template** from the Configure menu to display the following menu: Select a template and click **Edit**.

Each of the options in the above menu will open a list of permissions that may be enabled and disabled by clicking their respective check boxes.




Template options example: Security permissions

See the Appendix for permission descriptions.


Formats

Card types (e.g. Mastercard, Visa, Visa EMV, etc.) are added in the Formats menu.

Card and mailer formats can also be edited in the Formats menu to customize placement of text and pictures.




To add a card type, click **Add**. Enter the card's ISO or BIN number and select the card type. Click **OK**.



General Settings

The following menus are displayed by selecting a card type and clicking Edit.




The branch's core will be updated on every issue or reissue unless the above check boxes are selected.

To make hard-copy records of all queued transactions, including ordered cards and re-PINs, check the box in the **Transaction Report** section and select a printer.

Encode Settings


The Encode Settings determine the information and placement of information written to the cards' magnetic stripe.



To edit these settings, double-click the field to be changed to display the following window:



Click **OK** when editing is completed.



Card numbers may be generated automatically by TRISM in the **Auto Card Number** menu. Check the **Enable Auto Card Number Generation** box to edit card number settings.

Enter the first card number used as the **Beginning Card Number**. Cards will print with numbers beginning after the **Current Card Number**.

New card numbers can be automatically generated increasing by any increment by entering a number in the **Increment By** field.

The layout of a customer's name printed to a card may be changed by checking **Allow Name Change**.


Emboss Settings

Enter the size of the indentation applied to text on the card.


Check **Use Masking** to hide certain lines of text from displaying on the Order Card window when cards are being created.

Disable Truncation Rules: if a customer name exceeds a certain length, it will automatically be shortened to exclude a middle initial, prefix, suffix, etc. Checking the **Disable Truncation Rules box** disables this function so longer names must be shortened manually.

Check **Topping** if the printer being used has a roll of foil to top printed card names and numbers.



Mailers



Print Card Mailer or Print PIN Mailer: Enables printing of mailers upon card print.

<u>Use MSWord Mail Merge</u>: Use mailer templates from Microsoft Word documents.


<u>Calc Natural PIN</u>: Automatically generate a PIN for which the offset is 0000. When this is not enabled, the offset will be determined based on a randomly generated PIN.

Print Return Address: Include the branch's address on the PIN mailer.

Photo Settings

Configure .xml files, card number layout, photo ID's, custom backgrounds, and signature fields.

General



Setting Image Gallery Location

By the Template Directory Field, click **Browse**. The image gallery should be located in a folder with a name matching the branch ID, within the specified card type folder. For example: \\Server Name\\Images\\Card Type\\Branch ID

Template Parameters and Template Options

Check the fields that the card format .xml file contains.

Card Number Printing

No Spaces: Select for 18-digit cards to disable spacing between numbers Masked Card Number: Separate a 16-digit card number into 4 blocks of 4 digits Use Alt. Mask: Enter a string of "#" signs consistent with the desired spacing of card digits.

Advanced





Photo ID


Check **Format uses a Photo** for photo ID cards to enable the Take Photo button when ordering a card.

Click **Browse** and navigate to the folder containing the photo ID files.

<u>Naming Convention of Photo</u>: Photo ID images will be saved with a file name of one the following card properties:



These file names will be automatically masked, indicated in the Additional Properties field by the prefix "~MASK=".



Custom Background

Check **Allow Custom Backgrounds** to enable the Personalize button while ordering cards. This is intended for customer-provided images.



To set the location of the custom backgrounds, click <u>Browse</u> and navigate to the folder in which the backgrounds will be saved.

Signature

Check **Format Uses a Signature** if the card stock contains a signature box. Click **Browse** to navigate to the folder containing the signature images.

Card Status

The card status for each format will be chosen in the Order Card Job Information panel. For example:


New

Re-Issue

Replacement


Devices

The Devices tab displays a list of all printers and embossers configured with TRISM.



Each device must be licensed.


Once a license code is obtained, click Add **Device License**.




Enter the license code. Once a valid code has been entered, click **Install**. The Device License Allowed value will increase by the number of licenses linked to the license code.

Adding a printer or embosser


- 1. Install the printer according to manufacturer instructions.
- 2. Open the DSI Print Service Controller located in C:\Program Files\Demoteller.



- 3. Select the internal IP address (IP computer being used is on)
- 4. Enter the port assigned to the printer
- 5. Check Enable
- 6. Select the printer from the Installed Printers dropdown menu
- 7. Unless otherwise recommended, keep the Startup Delay at 0 seconds
- 8. Select the printer type from the Printer Properties dropdown menu. If your printer type is not listed, select "Other".
- 9. Click Print Size. Set the length and width to 6, then click OK. Do not change the Card Size unless otherwise specified.



- 10. Click Save Settings, then exit.
- 11. In the TRISM 4 Devices window, click Add.
- 12. If the printer will be accessed via network or wireless connection, select **Network**.



- 13. Enter the printer's name, IP address, port, and type (photo printer, embosser).
- 14. **If an embosser is being used**, select the desired options from the **Options** menu:

<u>Secure Mode</u>: enter embosser's data encryption key to encrypt information sent to embosser


Extended Errors: View a detailed log of any embosser errors

<u>Topper</u>: Check if a foil topping will be imprinted on card numbers and names <u>Auto Verify</u>: After a card is printed, it will be verified that is has printed correctly automatically. This is recommended when printing large quantities of cards. <u>Read First</u>: If a printer encodes information on a card's magnetic stripe prior to embossing, checking Read First enables the embosser to use that information to determine what is embossed on the card.

15. When all required information has been added, click **OK**.



An unlicensed device will be highlighted in red. Select the device from the Devices list and click **License Device**.




16. Click **Rebuild Devices** after adding, deleting, or changing a device.

Active Directory

All users part of a network's Active Directory may be automatically entered in TRISM. If Active Directory is enabled, usernames and passwords cannot be changed using TRISM IV. The computer in use must be part of a domain, **not a workgroup.** If the computer is part of a workgroup, do not change any active directory settings.

When Active Directory is enabled, the only non-active directory logins that may be used are:

Access1 Installer1 Installer2



Check the **Enable Active Directory** box. TRISM IV will automatically search for and enter the domain name.

Click **Get Domain Groups** to display all groups in the Users window.


Select a group in the Users window and choose a template from the dropdown menu.

Click **Set** to save the template to the selected domain group.


The domain group selected will appear in the Template Group field.

Branches

Each branch must be licensed. One free branch license will be included with TRISM 4. Additional licenses may be purchased from DSI.



Once a license code is obtained, click Add Branch License.




Enter the license code. Once a valid code has been entered, click **Install**. The Branch License Allowed value will increase by the number of licenses linked to the code. Select an unlicensed branch highlighted in red and click **License Branch**. A licensed branch will be highlighted in blue.

Add and remove vaults, devices, and PCs

Select a branch and click **Edit**. Click **Add** under Vaults, devices, or PCs and enter the name of the new vault, device, or PC.


Select an existing vault, device, or PC and click **Remove** to remove a branch.



Interfaces


Interface Settings

Interface settings and values will be determined by each individual interface and generally not edited by financial institution personnel.




Interface BIN Settings

Interface BIN settings determine what actions may be performed by each BIN. Interface BIN settings and values will be determined by each individual interface and generally not edited by financial institution personnel.



MSR

Magnetic stripe readers (MSRs), if used, must be licensed and linked to PIN pads.



Adding MSRs

Click **Add MSR License** and enter the license code obtained from DSI. Click **Test/Find MSR**. The MSR will appear on the table highlighted in red. Select the MSR and click **License MSR**. The MSR will now be highlighted in blue.

Moving an MSR to another computer:

Select the MSR to remove and click Release MSR.

When the MSR is plugged in to the new computer, click **Test/Find MSR**.

Inventory

The TRISM IV Inventory system features a dual control login to ensure security.




When an inventory is selected, a login window will open. Another user with inventory privileges (not the user currently logged in) must enter their username and password to gain access to inventory controls.

Vault Inventory

The vault inventory tracks the shipment of stock cards between the central vault and vaults at each branch.


Adding vaults

Click **Add Central** or in the Central Vault display or **Add Location** in the Vault display.



Enter the required name and address fields. Click **OK**.

Tracking cards



Sent Cards

- 1. Select a central vault. Click **Send Cards**.
- 2. Select the recipient branch's vault from the **Send To** dropdown menu.
- 3. Enter the Carrier Name, number of cards to send, and any additional comments.
- 4. Select the type of cards stock to send.
- 5. Click **Send**.
- 6. The shipment order will display under the **In-Transit Carrier** menu.

Received Cards

Select the received order under the **In-Transit Carrier** menu and click **Receive Cards**. The order will be removed from the In-Transit Carrier menu and the cards will be added to the vault inventory.

Device Access

Adding/removing cards and changing ribbon/foil

Each time a printer or embosser is opened, it must be accounted for in the Device Inventory.




- 1. Select the branch in which the device is located.
- 2. Select the vault containing the cards or foil.
- 3. Select the device to be opened.
- 4. If adding or removing cards, select card stock.
- 5. Enter the quantity of cards to add or remove, if any.
- 6. If opening an embosser to change topping and/or indent foil, check the corresponding boxes.
- 7. Enter a reason for opening and a description of the actions performed, or choose a reason and description from the dropdown menus. If adding or removing card stock, the reason will be generated automatically.
- 8. Select a time delay for unlocking the device. Longer delays should be used if the device is not near the workstation.
- 9. Click Process.



Card Stock Inventory

Card Stock ID

To add different card stocks to the inventory menus, enter the new card stock's ID and description in the provided fields.




Select whether the card should be printed readily, paused, or manually in the **State** menu.

Check the **EMV** box if the card stock has an embedded EMV chip.

Click **Add** once the above information has been entered.


Card Stock to BIN

To set the BIN number to be printed on each card stock type, select the desired



card stock in the drop down menu. Select the BIN in the drop down menu, then click **Add**.

Card Stock to Device




Track the addition of certain card types to printers and embossers.

Select the vault that contains the card stock to be added or removed, then select the card stock from the drop down menu. Select the printer or embosser in which card stock is added or removed, then click **Add** or **Remove**.

Request

Order Card



Search

If a core or processor interface is being utilized, select the interface from the dropdown menu.

If the customer is existing, choose to search by either card or member number. Enter the card or member number in the Search Criteria field.

Click Search.

Select the desired member from the list. The member's information will be automatically populated in the blank fields.

Card Information

Select the card BIN in the Product dropdown menu.

Click Get Card # to automatically generate the card number (if Auto Card Number is enabled in the BIN's format settings), or enter it manually.

Select the card stock from the drop down menu.

Enter the customer's name, business name (if desired), and the card's expiration date, if not automatically generated.

Click Get PIN. The PIN pad will beep. Enter the desired PIN on the PIN pad. Press the green Enter button.

The PIN pad will beep again. Re-enter the PIN and press the green Enter button to confirm the PIN.


The card's offset will be displayed after the PIN is entered.

Address, Security, Contact, and Account Information

If not generated by a core or processor interface, enter the member's information in the blank fields.

Job Information

Select items from the following dropdown menus:



^{*}Ready: Prints immediately

Manual: Prints when card is inserted into machine

Paused: Prints when card status is changes to Ready in the queue

Personalizing and Previewing Cards

In the Image Selection box, choose a galleried image from the dropdown menu. To insert a logo or choose a member-provided image, click Personalize. Click **Browse** and navigate to the folder containing the custom image.




Select the image and click Open.

To crop the image, click and drag an area on the image on the left. To insert a logo, select a logo color and position from the dropdown menu. Click **Save** when personalization is complete.


Click ${f Back}$ to preview the back of the card.

Click Order Card to send the card to the queue.




Edit Permissions

The Edit Permissions window allows a user to make certain fields in the Order Card window editable or required. The fields with editable permissions are highlighted in yellow.



Right click a field and select Is Editable to enable input of text.




Right click a field and select **Is Required** to make a field mandatory. If no information is entered in a mandatory field, when Order Card is clicked a red icon will appear next to the field.




A card may not be printed until all required fields are filled. Dropdown menus may not be designated as editable or required.

Re-PIN



- 1. Select Card Number or Member Number in the dropdown menu, then enter the customer's card or member number in the Search Criteria field.
- 2. Click **Search**. Results will be displayed in the bottom of the window.
- 3. Double click to select the desired card number.




- 4. Select the PIN Method. **PinPad** will allow the customer to manually enter the new PIN on the PINPad. **Generate** will automatically generate a new PIN.
- 5. Click **Get PIN**. If using the PIN Pad to enter the PIN, the PIN pad will beep. Enter the desired PIN on the PIN pad. Press the green Enter button. The PIN pad will beep again. Re-enter the PIN and press the green Enter button to confirm the PIN.
- 6. The card's offset will be displayed after the PIN is entered.
- 7. Click **Repin** to update the card record.


PIN Mailer

A PIN Mailer may be printed in this window if one is not printed at the time of card creation.

1. Enter the customer's member number in the Search Criteria and click **Search**.




2. Select the desired card number to populate the customer information.



3. Click "Print Mailer."

Queue

The queue displays all cards that have been ordered and have not yet printed.



Double-clicking an item in queue will display the Card Information:



Change job status: ready photo, send to embosser, manual print, paused photo, or card verified.


Delete a card in the queue by selecting it and pressing the Delete key on your keyboard.

If a Card Information window is open at another workstation or branch, the card cannot be printed, deleted, or changed. Click **Purge Requests** to close all Card Information windows.

Reports

End of Day

End of Day reports displays all cards and inventory changes made that day in selected devices and vaults. The table with the headers "BIN" and "Amount" show the quantity of each card type issued that day.



Tips for Balancing End of Day Reports

- Balance the end-of-day report *every day*. Never start the day with a device inventory greater or less than zero.
- Don't wait until the end of the business day to spoil cards. Spoil them as soon as they are incorrectly printed.
- Use the Device Access function to account for added or removed cards even if the device will be unlocked manually.
- The queue should be empty at the end of day.

Device Inventory

Starting Inventory: Quantity of cards in device at the beginning of the day (only greater than zero if cards are not removed at end of previous day)

Inventory Added: Quantity of cards added to device throughout the day

Inventory Removed: Total quantity of cards removed from vault device

Manually Added: Quantity of cards added manually during the order card process

Used Inventory: Quantity of cards not destroyed or returned to inventory; successfully printed cards issued to customers

Cards Destroyed: Quantity of cards destroyed in the Spoil Card menu

Cards Returned to Inventory: Quantity of cards returned in the Spoil Card menu

Other Cards Removed from Inventory: Quantity of cards removed from device not accounted for by the Spoil Card menu

Ending Device Inventory: Sum of the above quantities

Vault Inventory

Starting Vault Inventory: Quantity of cards in vault since last processed end-of-day

Vault Inventory Received: Quantity of cards received in the Vault Inventory Transfer page

Vault Inventory Sent: Quantity of cards sent in the Vault Inventory Transfer page

Removed to Device(s): Quantity of cards added to devices in the Device Access page (inventory menu)

Returned from Device(s): Quantity of cards removed from devices and returned to vault

Current Vault Inventory: Quantity of cards in vault

Total Cards in Device(s): Quantity of cards in all devices

Total Branch Inventory: Sum of cards in devices and vault(s)



If the Ending Device Inventory and/or Total Cards in Device(s) is greater or less than zero, the following window will appear:




Click Yes to process End-of-Day. Click No to return to the End-of-Day Report screen.


Spoil Cards

A misprinted card that cannot be issued is considered "spoiled." A spoiled card will be highlighted in red.

To give a user permission to spoil cards, click on the Configure tab. Click Templates from the left-hand menu and double-click the desired template. Select Queue from the left-hand menu, then check the box labeled **Delete Cards**. Right-click a card to display the following menu:



Select **Spoil This Card** to display the following window:



If desired, enter a description of the spoiled card and the reason for spoilage. Select from the following options:

Return to Inventory if the card is still viable for printing

Card Successful if the card was incorrectly spoiled and will be issued

Card Destroyed if the card is not viable for issuance or future printing


Click **OK** when finished. The card will be highlighted in red when successfully spoiled.

Spoil Other

If two cards are stuck together during printing, they must both be accounted for in the inventory.




Right click a spoiled card and select **Spoil Other**.




The Queue ID will display 0.

If desired, enter a description of the other spoiled card and a reason for spoiling. Select Return to Inventory, Card Successful, or Card Destroyed. Click OK. The Other Spoiled Card will appear in the queue.

If a card is mistakenly added to the queue via Spoil Other, right click it in the queue and select **Delete Spoiled**.




If a card is spoiled mistakenly, right click it in the queue and select **UnSpoil** to return it to its original state.



Management

Reports with user-specified information may be created in the Management tab.




Select the Start Date and End Date to specify a range of cards to display. The Start Date should be set one day prior to the date of card verification. Click **Search** to populate the list of cards.

<u>To open a previously created report</u>: select the report from the **Saved** dropdown menu.


To open a report template, select one of the following options from the PreMade dropdown menu:

Columnar Report: Prints all selected columns in specified date range Background Report: Prints card background summary in specified date range


<u>To create a customized report</u>: Select which columns are printed by right clicking anywhere in the card information field and selecting **Add/Remove Columns**.




Check the desired boxes to select or deselect the columns to be displayed.



To change the column order, select a column name and click the up or down arrows.



To filter columns: Select a column field from the first Filter dropdown menu.




Enter the filter criterion in the field below (only one criterion per filter). Only one filter field is enabled initially. Following filters will be enabled once preceding filters are designated.

Click **Search** to apply the specified filters.


Reports may be saved for future use, printed, or exported in .csv format.

To view card information: Right click a card and select **Details**.



Historical Card Balancing


Reports summarizing cards printed per branch, device, card stock, and/or operator can be printed in the Historical Card Balancing menu.



Select a date range, or click **Show All**. Select the branch, vault, device, and/or product in the dropdown menus to filter by and click **Filter** to generate the historical report.

Data Log

View the log of all actions performed by third party services.




Select the dates to search by in the Start Date and End Date dropdown menus, then select the service in which to view the log. Click **Search**.

Click **Purge** to delete the log.

Error Log

View the log of all errors encountered by third party services.

Select the dates to search by in the Start Date and End Date dropdown menus, then select the service in which to view the log. Click **Search**.



Click Purge to delete the log.

Help

About

View the version of TRISM IV currently installed.



Click Log Directory to view TRISM data and error logs.

Appendix

Card Layouts

Refer to the following guidelines when setting up card formats.


Card size	$3^{3}/_{8} \times 2^{1}/_{8}$ "
Bleed	¹ / ₈ " optimal; ³ / ₃₂ " minimum
Clearance	Text/logos at least ³ / ₃₂ " from edge of card, brand marks, magnetic stripe, EMV chip, or signature panel

VISA® Specifications

VISA® brand mark	.38" x .81"
Distance from right of brand mark to right edge of card	.08"
Distance from bottom of brand mark to bottom edge of card	.08"

Custom Images

Image file type	.jpeg
Aspect Ratio	3:2



Permission Descriptions

Locked: Disables user from logging in to TRISM

Add Printer: Add printers to branches

Edit Printer: Edit printers

Delete Printer: Delete a printer in branch

Security

Template Security Level: Determines for whom the user may reset passwords. Users

may reset passwords for users with security levels lower than their own.

Edit Security Template: Add templates

Edit Security Permissions: Edit templates

View All Branches: Displays the queue of all branches

Order Cards

View Order Card: Displays the Order Card tab in the main TRISM menu

View Actions: Shows Request dropdown menu

Edit Permissions: Shows Edit Permissions in the Request menu

With PIN Verification: Show RePIN option in the Request dropdown menu

Override: Show RePIN option in the Request dropdown menu

Order Card Express: Open the Order Card window upon login

PIN Mailer Only: Shows PIN Mailer in Request meun

Queue

View Queue: Displays the Queue tab in the main TRISM menu

Edit Card: Edit cards in queue

Delete Cards: Allows card deletion in the Queue

Delete from any Branch: Allows card in queue to be deleted from any branch

Purge Queue Requests: Shows Purge Queue Requests button

Reports

View Reports: Show Report dropdown in main TRISM menu

View Local Reports: Allows access to Management in the Reports dropdown menu

Run End of Day Reports: Allows Process End of Day button

Run End of Day Reports - User: Allows Show End of Day report dropdown menu

Run End of Day Reports - Admin: Allows Show End of Day report dropdown menu

Show Masked Card Number: Masks card numbers

View Non-Financial Reports: Allows non-financial report to display under

Management Reports

View Individual Reports: Show saved Management reports

View Existing Reports: Show Historical card balancing in Reports dropdown menu

Inventory

View Inventory: Displays the Inventory tab in the main TRISM menu

Device Unlock: Allows access to Device Access in the Inventory dropdown menu

View Card Stock: Allows access to Card Stock in Inventory dropdown menu

View Vault Inventory: Allows access to Card Stock in Inventory dropdown menu

Central View: Shows Central Inventory transfer

Central Admin: Allows adding Central vaults and sending cards

Central User: Shows options for Main Vault on right click

Branch View: Shows Branch Inventory transfer

Branch Admin: Allows adding a branch

Branch User: Shows options for Branch on right click

Configure

View Settings: Displays the Configure tab in the main TRISM menu

User Editing: Shows Users in Configure menu

Add User: Show "Add User" button Edit User: Show "Edit User" button

Delete User: Show "Delete User" button

Format Add: Show "Add" and "Copy" Format buttons

Format Edit: Show "Edit Format" button

Format Delete: Show "Delete Format" button Card Stock: Allows manipulation of card stock

Add: Add card stock

Delete: Delete card stock

Edit: Edit card stock

Rename: Rename card stock

General Edit: Shows General in Configure menu User Editing: Shows Users in Configure menu

Template Editing: Shows Templates in Configure menu

Format Editing: Shows Formats in Configure menu Device Editing: Shows Devices in Configure menu

Active Directory Edit: Shows Active Directory in Configure menu